

Security Advisory

Vulnerability in update process for Labeler and Checkweigher

BIZERBA-SA-2023-0001

1 Summary

Several vulnerabilities have been fixed within the software update process.

2 Affected Products

- Software GT-SoftControl < 6.0
- Lingx < 13
- Device firmware for product families CWx and GLx < 16.0

3 Mitigation

- Disable the FTP and SFTP services.
- Prevent unauthorized physical access to the devices.

4 Solution

Update software to the current version of the corresponding software.

5 Technical Details

The signature verification of the update process can be bypassed under certain circumstances.

6 CVSS Rating

The CVSS v3.1 Base Score is rated at: 8.1 (High)

CVSS:3.1/AV:N/AC:H/PR:N/UI:N/S:U/C:H/I:H/A:H

7 References

8 Timeline

- 2023-07-12: Vulnerability published